

We protect people

SafetyTracer manual

Mopas Lite

1. Functions and features	2
2. Safety instructions	2
3. Use	3
4. Alarmeren	4
5. Incoming calls	4
6. Status overview Mopas Lite	4
7. Technical information	5

Introduction

Thank you for using the SafetyTracer system. We have developed this application with the greatest care to enable you to sound the alarm when necessary. Unfortunately, despite all precautions, you may find yourself in a situation where you need help. SafetyTracer helps in such situations. You simply inform others and thus call in help. This manual has been designed with the greatest care. Should there nevertheless be any imperfections in it or should you have any other improvements or remarks, we would like to hear from you.

1. Functions and features



2. Safety instructions

Please read these safety and user instructions carefully before using the Mopas Lite. Keep this owner's guide for reference when necessary.

Information

Follow the safety instructions and the instructions in this manual. If you have any questions or uncertainties, please contact your supplier. General information can be found at www.safetytracer.eu.

Safety precautions

For the correct and safe installation and use of the Mopas Lite, it is essential that you observe the generally accepted safety measures in addition to the additional safety information in this manual. Additional warnings and safety notes are included in this manual where applicable. Warnings and safety phrases and/or symbols are marked on the equipment as necessary.

Accountability

SafetyTracer portal reserves the right to change the data and/or specifications of any device or software mentioned in this publication without prior notice. Despite all care taken to ensure the accuracy of this publication, SafetyTracer is not liable for any damage caused by improper use or contempt of this publication.

Important safety notes:

- Read all safety instructions and manuals carefully before using.
- Keep all safety instructions and manuals for future reference.
- All warnings on the equipment and in the manuals must be followed for personal safety reasons.
- Never clean the Mopas Lite with liquid or aerosol cleaners, but use a damp cloth to clean.
- Do not connect equipment other than that recommended by SafetyTracer portal. Failure to follow the recommendations may result in malfunctioning of equipment and systems.
- Do not place the equipment in humid or outdoor areas without additional protection if it is not expressly designated for that purpose.
- Do not expose the equipment to extreme temperatures or humidity.
- Do not expose the equipment to strong magnetic and electromagnetic fields.
- Do not place the equipment on an unstable or vibratory surface.
- Do not place heavy objects on the equipment.
- Avoid violent shocks during transportation.
- The equipment may only be powered by a power supply that conforms to the equipment specification.
- Opening or removing the housing can touch live parts.
- Do not attempt to service or repair the equipment by yourself. Maintenance and repair work must be carried out by sufficiently trained and qualified personnel.

3. Use

Before you can use the Mopas Lite, you must follow the steps below. Check that the supplied SIM card is inserted correctly into the Mopas Lite.

Attention!

The supplied SIM card only works in this specific Mopas Lite that is supplied to you. If the SIM card is used in combination with another device. Then the SIM card is automatically blocked and unusable. The Mopas Lite will also no longer alarm after it has been replaced in the Mopas Lite. If this happens, please contact your partner who supplied the Mopas Lite.

Charging

For first use, the Mopas Lite needs to be charged for 2-3 hours. Charging the device is done as follows:

Micro-USB cable charging

Insert the micro USB plug of the side adapter into the Mopas Lite. Then plug the adapter into the wall socket.

Magnetic USB cable charging

Optionally, a magnetic USB cable can be supplied. This magnetic USB cable makes it easier for the user to charge the Mopas Lite. Insert the magnetic USB cable into the Mopas Lite and "click" the charger magnetically to the Mopas Lite.



Figuur 3.1

Battery status

Red light on, this means that the device is charging. The blue light is on continuously, here the device is fully charged. Without intensive use of the device, the battery will last for about 2 days.

4. Alarmeren

To create an alarm, press the SOS alarm button. The alarm button should have two seconds to activate the alarm. To confirm that you have set the alarm, a sound will be produced. Also, the device will vibrate for a short time.

As long as an alarm has not been accepted and handled by a caretaker, the Mopas Lite will remain in alarm mode. In this alarm phase, no new alarm call is possible.

The alarm is sent from the Mopas Lite to the Mopas Cloud Monitoring System, which then forwards it to the care provider(s). The care provider can then set up a speech/listening connection with the Mopas Lite. A conversation can then be held as with a normal telephone. When the care provider calls the Mopas Lite, a conversation is established immediately.

A conversation between the care provider and you is only possible if you have pressed the alarm button. In all other cases the Mopas Lite cannot be contacted by telephone.

Attention!
After handling the alarm it is wise to put the device on the charger immediately.

5. Incoming calls

Incoming calls can be answered by pressing a button on the front of the device. Except for the on/off button, it is used to reject a call. When the power button is pressed briefly, the time will be read by the device.

By default, the Mopas Lite is delivered with the option Automatic Answer on on. This means that an incoming call to verify an alarm call will be automatically answered by Mopas Lite. When an incoming call comes in, the Mopas Lite will vibrate and make a short sound to alert the user to the incoming call. After that Once this has happened, the user of the Mopas Lite can talk to his caregiver.

Optionally, the Automatic answer function can be disabled.

6. Status overview Mopas Lite

The Mopas Lite has two lights at the front. One red and one blue. Below a description of the most common combinations.

LED	Description	Meaning
Flashes blue	GPS indicator	GPS searches for the device's location
Flashes red	Network indicator	The device is searching for a network connection
Flashes accelerated blue	GPS indicator	GPS location is found
Flashes accelerated red	Network indicator	Network connection has been found

7. Technical information

User interface	Normal GPS (LED blue and red accelerated) In case of alarm Data communications (LED red) Battery low Data communication (LED blue)
GPS positioning accuracy	5 m - 15 m (open sky)
WiFi ning accuracy	15m - 100m (WiFi area)
LBS ning accuracy	100m - 1000m
Ambient temperature	-18 °C tot +70 °C
Humidity	5% ~ 95% RH
Dimensions	40,5 x 43,4 x 13,8 mm
Weight	25 g
Battery capacity	500mA