

A pocket-sized **companion**



Index

1. Package contents	3
2. Product overview	3
3. Charging station	3
4. Safety instructions	4
5. First use	5
6. Make an alarm	5
7. Led indicators	6
8. Technical specification	6
9. Recycle information	7

Introduction

Thank you for using the SafetyTracer system. We have developed this application with the utmost care to enable you to sound the alarm when necessary. Unfortunately, despite all the precautions, you can end up in a situation where you are in need of help. SafetyTracer helps in such situations. You simply inform others and thus call in help. This manual has been prepared with the utmost care. If, in spite of this, there are imperfections or if you have other improvements or remarks, please let us know.

1. Package contents

1. Kompy Pico
2. Magnetic charging cable
3. Power adapter



2. Product overview

1. On / Off & Call button
2. Panic button (SOS)
3. Microphone
4. GPS LED light
5. GSM LED light
6. Speaker
7. Charging contact pins



3. Charging station

Optionally there is a charging station available for the Kompy Pico. With this charging station it is even easier to charge the Kompy Pico. (The buttons on the charging base are non-functional)

- To use the charging station, you first connect the cable that is located on the bottom of the station to the provided power adapter.
- Plug in the adapter. A blue ring will now light up on the charging station.
- The charging station is now ready for use.
- To charge the Kompy Pico, simply place it into the charging station.



4. Safety instructions

Please read these safety instructions and user manual carefully before using the Komy Pico. Keep this user manual for reference when needed.

Information

Please follow the safety instructions given in this manual. If there are any questions or ambiguities, please contact your supplier.

General information can be found at www.safetytracer.eu

Safety precautions

For the correct and safe installation and use of the Komy Pico, it is essential that you follow the generally accepted safety measures in addition to the additional safety information in this manual.

Additional warnings and safety notes, if applicable, are included in this manual.

Warning and safety texts and / or symbols have been placed on the equipment if necessary.

Safety statement

This equipment has been tested to comply with safety certificate in accordance with the specifications of standard: EN 60950: 2006 + A12: 2011.

Liability

SafetyTracer BV reserves the right to change data and / or specifications of any device or software mentioned in this publication without prior notification. Despite all the care that is devoted to the correctness of this publication, SafetyTracer BV is not liable for damage caused by incorrect use or contempt of this publication.

Important safety instructions:

- Read all safety instructions and manuals carefully before proceeding to use.
- Save all safety instructions and manuals for future reference.
- All warnings on the equipment and in the manuals must be followed because of personal safety.
- Never clean the Komy Pico with liquid detergents or cleaning agents from an aerosol dispenser, but use a damp cloth to clean.
- Do not connect any equipment other than the equipment recommended by SafetyTracer.
- Deviating from the recommendations may lead to malfunctioning of equipment and systems.
- Do not place the equipment without extra protection in humid environments or outdoors if it is not explicitly stated that the device has been designed for this purpose.
- Do not expose the equipment to extreme temperatures or humidity.
- Do not expose the equipment to strong magnetic and electromagnetic fields.
- Do not place the equipment on an unstable or vibrating surface.
- Do not place heavy objects on the equipment.
- Avoid strong shocks during transport.
- The equipment may only be supplied with a power supply in accordance with the equipment specification.

- By opening or removing housing, live parts can be touched.
- Do not attempt to maintain or repair the equipment independently. Maintenance and repair work must be carried out by suitably trained and qualified personnel.

5. First use

Before the Komy Pico can be used, you must carry out the following steps.

Opladen

To charge the Komy Pico, connect the provided charging cable to the adapter and plug in the adapter. Connect the magnetic charging cable to the charging pins on the back of the Komy Pico. The red LED will blink slowly during charging. It is recommended to charge the device for 4 hours before first use.

Activate

You can turn on the Komy Pico by pressing the On/Off button for 3 seconds.

If you want to turn the device completely off, press and hold the on/off button and the SOS button for 3 seconds simultaneously.

6. Make an alarm

An alarm will be created by pressing and holding the alarm button for 3 seconds. There will be a beep sound and the green light of the Komy Pico starts blinking.

When the alarm is activated, the alarm will be automatically forwarded in our platform to the appropriate caregivers or care center.

As long as an alarm has not been accepted and handled by the caregiver, the Komy Pico remains the alarm. In this alarm phase, a new alarm call is not possible.


If the alarm is accepted by the caregiver, a voice connection can be made to start a conversation. If the caregiver calls to the Komy Pico, a conversation will be established.

A conversation between the caregiver and you is only possible if you have pressed the alarm button. In all other cases, it is not possible to make a voice connection with the Komy Pico.


To end the alarm, press the alarm button.

7. Explanation of LED indicators


Green LED



Slow blink = Searching for GSM network



Single blink = Connected to GSM network




Double blink = Connected to GPRS network




Steady light = No or faulty SIM card

Blue LED



Slow blink = Searching for GPS signal



Single blink = Connected the satellite

8. Technical specification

Size	60mm x 41mm x 16mm
Weight	44g
Battery	900 mAh Li-ion, rechargeable
Standby	120 hours
Operating Temperature	-10°C tot +60°C
IP Class	IP65
Approval	in accordance with the standard R&TTE 99/CE/05

9. Recycle informatie



The symbol on the product or its packaging means that this product must be disposed of separately from ordinary household wastes at its end of life. Please be aware that this is your responsibility to dispose the electronic equipment at recycling centres to help conserve natural resources.

For more information about your recycling drop off point, please contact your local electrical and electronic equipment waste management authority or the retailer where you bought the product.

- Do not dispose of the Kompy Pico with household waste.
- Batteries are not to be disposed of in municipal waste stream and require separate collection.
- Disposal of the packaging and your Kompy Nano should be done in accordance with local regulations.